


# ◆ Instructions for Replacing Battery ◆

---

Schematic diagram:




## Step 1

Pull down the base.



## Step 2

Remove the base and take off the screws by screwdriver.



## Step 3

Change the batteries.