


• Battery Replacement Included Batteries: 2 x CR2032 3V



*The internal parts of the button are small and numerous, please be careful when disassembling

• Velcro strap



• Lanyard



Please scan for detailed operation